

Compact ventilation units Series SupraBox COMFORT / Overhead version



SupraBox ... D



SupraBox ... D








BA113BB10/12/A/ SupraBox

Index	Seite
1. General Safety Information	2
1.1 Warning regarding Health and Safety	2
1.2 Safety Instruction	3
2. Technical Manual	4
2.1 General Description	4
2.2 Device Overview	5
2.3 Device drawings.....	6
2.3 Device drawings.....	7
3. Operating conditions	9
4. Delivery, Transport and Storage	10
4.1 Delivery	10
4.2 Transport	10
4.3 Storage	13
5. General Installation Instructions	14
5.1 Installation of the unit	14
5.2 Assembly	14
5.3 Connection of the ventilation ducts to the unit	15
5.4 Electric Installation	16
5.5 Connection of the condensate, exhaust air and overflow pipes	16
6. Startup and Operation	17
6.1 General startup information	17
7. Maintenance and Cleaning.....	18
7.1 General Maintenance Instructions	18
7.2 General Cleaning Instructions.....	18
7.3 Maintenance and Cleaning of the housing and control	19
7.4 Fans.....	20
7.4.1 Initiation	20
7.4.2 Use	22
7.4.3 Maintenance and Cleaning	22
7.5 Reverse flow heat exchanger	23
7.5.1 Startup	23
7.5.2 Operation	23
7.5.3 Maintenance and Cleaning	24
7.6 Panel filters	26
7.6.1 Startup	26
7.6.2 Operation	26
7.6.3 Maintenance and Cleaning	26

1. General Safety Information

1.1 Warning regarding Health and Safety

The following icons inform about certain hazards or safe use.

	Attention! Danger! Safety Advice!
	Hazard by electricity or high voltage!
	Crush hazard!
	Danger Overhead Hazard!
	Caution ! Hot surface
	Beware of falling objects
	Important Advice, Information

1.2 Safety Instruction



At the time of delivery the Rosenberg SupraBox Comfort series is constructed and produced according to the latest technical standard. Substantial tests of material, function and quality guarantee a high value and a long lifetime. When improperly used by untrained staff or not according to the instructions these machines can be dangerous.



Read these instructions carefully prior to unpacking, assembling or performing maintenance!

- The system may only be used after installation.
- The following work must only be performed by trained specialists:
 - Assembly
 - Electrical connection
 - Connection of power terminals
 - Maintenance work
- Please use the compact ventilation appliance only according to the regulations within the prescribed power limit. The power limit is included in the technical data specification or can be found on the name plate. One single instance of the prescribed power limit being exceeded will inevitably cause damage to the built-in components which results in the safe use of the appliance being compromised.
- Only approved material handling equipment may be used. Please consult your local institutions or relevant regulations for the appropriate range.
- Prior to working on electric machines these have to be disconnected from all poles (padlockable selector switches with appropriate capacity and function are included in the delivery and pre-installed).
- Service and maintenance operations must be performed only with appropriate protective clothing and safety helmets, as these operations are overhead work.
- After completion of work on the RLT-appliance the responsible person must ensure that nobody is working on the installation before it is re-started.
- Authorized persons must be instructed according to the normal accident prevention regulations of the corresponding Employer's Liability Insurance Associations and be trained in their work area.

Read also:

BGV A1	„General Instructions“
VBG 5	„Power-driven work equipment“
VBG 9a	„Load bearing equipment for hoist operations“
BGV D27	„Industrial trucks“
BGV A3	„Electrical systems and equipment“


2. Technical Manual

2.1 General Description

- According to the EC Machinery Directive, stationery ventilation appliances have to be electrically connected to a breaker and series fuse. It must be possible to disconnect the unit from all poles!
- The unit corresponds to the requirements of VDI 6022 and DIN 1946 T6.
- Depending on the size of the installation the range of application extends to a power volume of 1.900 m³/h with 250 Pa ext. pressure and a maximum flow medium density of 1,3 kg/m³.
- The application area includes the air treatments: filtration, heating, cooling, and moving. In addition heat recovery with high efficiency is used.
- Energy-efficient compact ventilation unit. Heat recovery through an aluminium reverse flow recuperator with very high efficiency. It can be dismantled for cleaning and condensate will be dissipated in a condensate pan with gradient all around.
- Unit is ready/prepared for connection to isolation/drop rod by the customer.
- The compact housing consists of corrosion-resistant, double skin, coil coated and galvanised sheet steel; quality: DX51D + zinc 275 + additional org. coating min. 25 µm RAL 7035; metal gauge 1.00 mm.
- Sidewall panels, housing bottom, housing cover, rear panel and doors (with double skin) are equipped with 40 mm internal acoustic and heat insulation (min. 33 kg/m³; $\lambda = 0,04 \text{ W/m} \times \text{K}$).
- The direct drive fans with backward curved centrifugal impellers are installed with vibration absorption. The drive will be effected by two energy-saving and 100% infinitely variable EC-motors.
- Filtration of external air F7 and exit air F5 through particulate panel filters.
- The ventilation unit will be delivered with integrated control. This is easy to maintain and installed in a terminal box on the sidewall of the housing. It is completely wired and tested by the manufacturer.
- The unit is clearly labelled with symbols and text for easy operation. An external controller for the managing the whole system is included.

2.2 Device Overview


SupraBox Comfort		1100 D	1900 D	
Housing		Double skin 40 mm frameless	Double skin 40 mm frameless	
Size (L x W x H)		1755 x 1292 x 440 [mm] Incl. Regulation box and connection branch	1600 x 1892 x 440 [mm] Incl. Regulation box	
Operating Point		1100 m ³ /h at 200 Pa	1900 m ³ /h at 250 Pa	
Fans	Backward curved, free running, driven by highly efficient Rosenberg – EC-external rotor motors with integrated electronics			
Power Input In the operating point		2 x 320 W	2 x 750 W	
SFP-Value In the operating point		1048 Ws/m ³	1421 Ws/m ³	
SFP class In the operating point		SFP2	SFP3	
Heat recovery Efficiency	Reverse flow -plate heat exchanger up to $\eta=92\%^*$, corresponding to WRG-classes H1 *Maximum value on condensation; Heat recovery dependant on the operating condition			
Air filter	Panel filter with plastic frames incoming air: F7 extracted air: F5			
		358x553x96 [mm]	358x848x96 [mm]	
Air Supplies		horizontal DN 315	horizontal 330 x 480 [mm]	
Control	Incoming air/extracted air/room temperature control, Fans 3-steps, steps adjustable Bypass-function modulating 0 – 10V with anti-freezing monitoring Activation of optional equipment according to size and facilities			
Max. total current consumption		4 A	9 A	
Overall sound power level				
Suction side L _{WA5}		60 dB(A)	64 dB(A)	
pressure side L _{WA6}		80 dB(A)	87 dB(A)	
Housing L _{WA2}		53 dB(A)	63 dB(A)	
Weight incl. control		188 kg	270 kg	



Picture: drawing of the device **overview**
SB110DGRIB00


- | | |
|---------------------------------------|---|
| 1 Panel filter exhaust air F5 | 7 Loops/ transport loops |
| 2 Reverse flow heat exchanger | 8 Control box incl. control system |
| 3 Bypass flap | 9 Supply fan with EC-motor |
| 4 Condensate pan | |
| 5 Panel filter incoming air F7 | |
| 6 Exhaust fan with EC-motor | |

2.3 Device drawings



- A hose with appropriate hose sleeve is recommended for the condensate drain

Suprabox 1900 D (SB190DGRIB00)



- A hose with appropriate hose sleeve is recommended for the condensate drain

3. Operating conditions




The Rosenberg compact series SupraBox Comfort is exclusively made for treating air or gaseous media according to the criteria stated below!

The compact ventilation appliance is suitable for the conveyance of:

- Clean air, low dust air or low greasy air
- Slightly aggressive gases or fumes (consult the factory in either case!)
- Gaseous media up to a density of 1,3 kg/m³
- Gaseous media up to a relative humidity of max. 95%
- Gaseous media in a temperature range of –16°C to +40°C. (higher or lower ranges require special modifications!)
- Non-explosive gaseous media

4. Delivery, Transport and Storage


4.1 Delivery




Rosenberg-Supraboxes must be checked for damages immediately on delivery. This should be made before unloading the device from the transport vehicle. Furthermore the completeness of the delivery scope must be checked in accordance with the freight documents. Missing parts or damages must be noted immediately on the freight documents and signed by the driver of the transport vehicle.

4.2 Transport

The unit will be delivered on a customized single use pallet and can be moved with a forklift or a pallet truck. The transport dimensions (incl. control box) and weights can be found on the drawing below:



Suprabox	L	W	H	Weight
1100 D	1900 mm	600 mm	1460 mm	205 kg



Picture:: transport dimensions Suprabox

Suprabox	L	W	H	Weight
1900 D	1800 mm	2000 mm	600 mm	315 kg




- Avoid twisting, bending or other physical damages of the housing when hoisting the device!
- Keep the control doors closed during transport!
- Always use proper hoisting machines!
- Please note that excessive loads on the housing may cause damages!
- For your own safety use appropriate anti-slip gloves and safety shoes for the transport.

For the **transport with forklift or pallet truck** please note the following instructions:




- The transport with industrial trucks requires regular training of the responsible staff according to the accident prevention regulation (in Germany BGV D27 „Flurförderfahrzeuge“).
- The loading capacity of the material handling equipment must always be checked before loading!
- The fork length of the material handling equipment must be greater than the length of the transport pallet to be picked up. Forks which are too short cause damage to the floor panels.




Picture: Unloading by forklift

For the **transport with a hall crane or a truck crane** please note the following instructions:




- The transport with cranes or lifting fixation devices requires regular training of the responsible person according to the accident prevention regulation (in Germany VBG 9a „Lastaufnahmeeinrichtungen im Hebezeugbetrieb“)
- Danger Overhead hazard! It is forbidden to stay below floating loads!
- For direct load attachment (underdragging the load) only use exclusively licensed, undamaged fabric slings with sufficient contact surface and edge protection. (e.g.: webbing slings according to EN1492-1 or round slings according to EN1492-2)
- It is forbidden to use chain slings or slinging ropes for the direct load attachment!
- The slings should not have an inclination angle of more than 60°!

Inclination angle
greater than 60°




Picture: Transport by crane

Inclination angle
smaller than 60°




- Please note distribution of is usually out of visible from the functional part!

Heavy load




niedrige Belastung

that when lifting the the functional part balance! This is not outside of the



- Only use carrying devices with the same length.
- Make careful and none jolting movements.
- Avoid setting the load down hard and bumping.

4.3 Storage




- Make sure to store the unit in a dry and weather protected area!
 - On receipt of the merchandise the packaging, film and tape must **immediately** be removed in order to avoid condensation!
 - Open pallets must be covered by tarps. Protect the functional parts against pollution (e.g. chips, stones, wires etc.).
- Keep the storage temperature between -16°C and +40°C, avoid high humidity.
 - If storing the unit for more than 12 months make sure the fan turns freely before installation.



► *Manual rotation of the rotor*

5. General Installation Instructions

5.1 Installation of the unit



The Rosenberg-SupraBox Comfort overhead version must be installed on a ceiling which is professionally constructed and statically suitable for this specific use.

Assumption of static or dynamic building functions by Rosenberg devices must be excluded. Otherwise the warranty by Rosenberg Ventilatoren GmbH will expire for damages to the device or resulting damages to the building.

Installation and assembly may only be made by trained staff, familiar with the specific accident prevention regulations and general safety-related and occupational health laws.


In addition to the static analysis for the overhead construction also consider the following instructions:

- The suspension must be level and without torsion.
- The horizontal inclination angle of the device may not exceed a maximum of 2%.
- Choose an installation space with an unobstructed condensate drain and water trap, as well as a sufficient gradient of the condensate line.
- The height level between installation space and the floor/intermediate ceiling must guarantee a professional condensate drain from the functional parts.
▶ **Consider the height of the waste trap!**

In order to ensure low noise operation consider the following advice:


- Low air velocity in the duct
- Do not install the device on a wooden ceiling
- Use a vibration resistant ceiling construction

5.2 Assembly




Get an overview of the quantity and description of all functional parts with help of the enclosed technical documents. Under item 2.2 unit overview or 2.3 unit drawing respectively there is a detailed drawing with all relevant dimensions.

For an installation of the SupraBox in the intermediate ceiling or the area of operation respectively the inspection opening and space to the floor must be big enough for maintenance and revision. Permanent access must be guaranteed.



It is important to have sufficient space for operating and maintaining the unit underneath the suspended Suprabox. The condensate drain connection installed by the customer must be removed before opening the exhaust air door. The device must be fixed at the loops/transport loops.



Picture: revision area

Suprabox	R [mm]	T [mm]
1100 D	520	960
1900 D	520	960

The compact ventilation appliance will be completely wired for plug-in and checked by the manufacturer. They are equipped with an integrated control system. Only the connections for the ventilation ducts, the condensate and water must be properly installed on site. Furthermore the electrical supply as well as external sensors or optional accessories such as duct heaters etc. must be connected.

The remote operator control must be connected to the control system using the provided cable and placed at the ventilation unit or nearby. The electrical connection has to be made according to the wiring diagram, see the additional operating manual for the control system.


5.3 Connection of the ventilation ducts to the unit



The connection sleeves of the Rosenberg-SupraBox Comfort overhead versions are provided as circular tube spigots, with T-sealing lip (1100D) or as rectangular connection (1900D), sizes as shown in the unit drawings. The duct system must be installed according to the valid technical standards and regulations and must support the dead load by installations of the customer. Additional requirements concerning

sound insulation can be met by separate vibration isolation with elastic connections. These are usually not included in the delivery, but can be provided as additional equipment. The external air and exhaust air duct must be protected against condensate water.

5.4 Electric Installation



The electric connection must be exclusively made by a licensed electrician according to the VDE-regulations. The connection must be made exactly according to the wire diagram and face plan.

Check all screw joints before startup of the unit and if necessary retighten them.


Further installation information can be found in the separate operating manual of the control system.



5.5 Connection of the condensate, exhaust air and overflow pipes

The Suprabox is equipped with a condensate pan including an all-side gradient in the exhaust air. The condensate drain consists of an aluminium circular tube of 15 x 2 mm. To ensure that the exhaust air maintenance door can be opened, we recommend an appropriate flexible hose with a circular cuff for connection.


Especially in the cold seasons there could be condensate in the exhaust air duct of the reverse flow heat exchanger. In order to make sure the condensate drains correctly via the condensate pan and to avoid air leakage it is important to attach a vacuum trap. Alternatively a hose can be fixed at the unit to replace a trap. The minimum size must be observed by the customer. Fill the trap with water before startup. Protect the trap against desiccation and in cold areas against frost. Do not connect the spout to the sewage system. Alternatively a vacuum trap with non-return ball can be used but make sure that there is a suction lift of at least 70 mm.



Picture: minimum size trap

6. Startup and Operation

6.1 General startup information



Prior to the startup of the compact ventilation unit observe the instructions below:

- Inspection of the proper installation, connection and assembly
- Free air connection, free suction holes
- Free running of the fan wheels
- Closed valves at the heat exchanger units
- Check the screw joints of all connections
- Unlock the electric duct heater only after the fan
- Remove a possible protective film
- Optical inspection of the unit gaskets for damage
- Re-adjust the hinges of the maintenance doors
- Close all doors
- Operational check of the fans
- Pressure control of the reverse flow heat exchanger must be set according to the operating point of the unit.



► **Attention:** If the above instructions are not followed, dangerous conditions may occur on startup of the unit, which affect the functionality and safety of the unit.

remove water



► **ATTENTION:** Before stopping the unit de-energize it and of optional heaters to avoid freezing.

Further information for the startup of the units can be found in the corresponding component specification beginning with item 7.4. The instruction manual of the control system must absolutely be observed!

7. Maintenance and Cleaning

7.1 General Maintenance Instructions



The maintenance interval indicated in this manual basically refers to the transport of normally polluted air. If the unit must transport strongly polluted air the maintenance intervals must be reduced accordingly.

► Before any maintenance work is started the unit must be stopped properly and all poles disconnected from the mains. Proceed in the following order.



1. Stop the unit using the remote operator. Activated full automatic weekly programs have to be deactivated first.

2. Wait 2 minutes until the optional louver damper is closed and the fans have stopped.



3. Now turn the operating switch to ZERO (Off) and make sure that it will not be switched on unintentionally. This step disconnects the compact unit from the mains with all poles. Be aware that the control box will still be hot. For maintenance at the control box the connection must be interrupted.

4.



Wait for the residual voltage to decrease at the EC-control as indicated in the instruction manual of those components.


5. Let

the heater cool down.

6. Now you can open the maintenance doors.

Pay attention that at optionally used channel-type heat exchangers the water circulation is protected against re-starting.

7.2 General Cleaning Instructions



Recommended cleaning agents for surface disinfection are:

- Dismozon pur (Bode Chemie)
- Melsitt (B.Braun)
- Antifect (Schülke & Mayr)
- Clorina (Lysoform)

All disinfectants are recognized and licensed by Robert-Koch-Institute (date 31.05.2007, 15. edition)


To ensure the hygienically perfect condition of the unit the following instructions must be observed:

- Only qualified and trained staff should clean the unit (in Germany according to VDI 6022).

- The hygiene inspection at the unit has to be made according to the following intervals:
 - after startup
 - every 3 years (units without moisturization)
- The periodical hygiene inspection is necessary to reveal hygiene deficiencies at an early stage and to rectify them with appropriate action.
- The results of the inspection of the hygienic condition, the cleaning and disinfection have to be documented in the appropriate way (e.g. operations diary).
- The relevant regulation for the hygienic requirements of the RLT-units is VDI 6022. It is the guideline for the current instructions. All work has to be carried out according to the latest version of the VDI guideline.

Please find instructions for the cleaning and hygiene inspection of each functional part of the device below:

7.3 Maintenance and Cleaning of the housing and control



Please keep to the following instructions for the regular maintenance work (quarterly intervals):

- Check the seals of the control doors and replace them if necessary
- Check the panels for damages and corrosion
- Flexible parts, such as hinges, should be treated with an appropriate lubricant spray
- Remove severe loose dirt with a vacuum cleaner
- Remove other dirt with a moist cloth
- The water or cleaning agent should have a neutral ph-value (6-8)

Maintenance of the control and terminal box (only carried out by an electrician)	Every 3 months	If necessa ry	Hygiene inspection
Check the electrical equipment, cables and connections for dirt and apparent damages and replace them if necessary.	X		
Dry cleaning of the control, do not use water		X	


7.4 Fans

7.4.1 Initiation



- Before connecting the unit to the mains the initial operation should be made according to the VDE regulation
- Make sure that the operating switch is set to ZERO (OFF) and protected from restarting before you open the fan enclosure.
- The fans should be operated exclusively while installed, only after correct installation of the protection unit (suction protection) and with closed doors.
- Before the startup of the fans check the heat recovery, the heater and the corresponding frost protection if the outside temperature is less than 5°C and operate them if necessary in order to prevent the unit from frost damage.
- Check the unit for forgotten tools, foreign materials and dirt and clean it if necessary.
- Check all clamping elements of the fan to ensure that they are properly fixed.

- Motor and fan bearing
- Fan wheel
- Vibration absorption




picture: fan Suprabox D



- Before starting the power supply it is necessary to check if all assembly components are ready for use and to adjust them.
- Check the correct function of the fan when you start it up (air supply, balance, vibration or imbalance).
- **Remove all 3 transport locks of each fan** by unlocking the M6 screws. First remove the inlet cone plate then adjust the inlet cone.
- Check the gap and the gap cover according to the following drawing:

- ► Check of the gap and the gap coverage between wheel and inlet cone



- The gap S should be constant on the entire perimeter of the wheel.
- The gap cover R should be about 1 to 2 % of the wheel diameter.
- **Adjustment of the cone:**
 - If the wheel is rubbing at the cone after installation of the unit adjust it as follows:






Abb.: Adjustment of the cone

7.4.2 Use



Monitor the fans for correct function during operation. Vibrations, pressure fluctuations or other deviations from the provided operating parameters should be checked according to the following chapter:

7.4.3 Maintenance and Cleaning




Monitor the unit operation during the first four to twelve weeks regarding the following points:

- Balance, unusual sounds, vibrations
- Fastening of the fan, the motor and the vibration absorbers

The fan as a fast rotating device needs regular monitoring as well as a three-month maintenance interval. In case of deviations from the standard operational conditions (air temperature, increased dust pollution or constant high humidity) or in case of continuous 24-hour operation a shorter interval must be determined.

Maintenance fan unit	Every 3 months	If necessary	Hygiene Inspection
Check the fan for dirt, mechanical defects, corrosion and proper fastening	X		X
Check the fan gap	X		
Clean the fan unit incl. wheel		X	
Check the wheel for imbalance	X		
Check the quiet running and the bearing for sounds	X		
Lubricate or replace the bearing		X	
Check the fan fastening for tightness and mechanical damages	X		
Check the function of the vibration absorber	X		
Check for the existence of the fasteners of the protection units.	X		
Check the function of the drainage	X		X
Check the motor for dirt, mechanical defects, corrosion and proper fastening	X		X
Cleaning of the motor housing		X	
Check the power supply	X		
Check the electrical connections for corrosion and proper fastener	X		



For more thorough cleaning the fans can be removed. Make sure that before removing the fans the wiring will be disconnected by qualified and trained staff according to the wiring diagram. Now the allen-head screws of the cone plate can be unlocked and the fan carefully removed.

The water or the cleaning agent respectively should have a neutral ph-value (6 – 8).

7.5 Reverse flow heat exchanger


7.5.1 Startup



Check the correct operation and direction of movement of the bypass flaps of the reverse flow heat exchanger. Make sure that the bypass flap is closed on startup of the fans.


Pay attention that the drain pan at the bottom of the reverse flow heat exchanger in the exhaust air is fixed to the condensate pipe by a trap (at the suction side). The assembly of the trap is described under point 5.5.

7.5.2 Operation




The automatic bypass flap will be controlled by the central device control using a final control element.

7.5.3 Maintenance and Cleaning



The reverse flow heat exchanger as an installed component needs little maintenance. For hygienic requirements inspection and maintenance is necessary. In addition the integrated damper servomotor and fastener need regular checks and maintenance.

In case of heavy dirt the reverse flow heat exchanger can be removed with the following steps and safety measures and cleaned under running water.



Picture: Detachment heat exchanger

- 1 Fixing bracket heat exchanger
- 2 Clamping heat exchanger
- 3 Front panel heat exchanger
- 4 Reverse flow exchanger 1
- 5 Reverse flow exchanger 2
- (6) Reverse flow exchanger 3 (only 1900D)



In order to ensure safe removal of the heat exchanger, follow the order of the steps below:

1. Unlock the front panels ([3] pict. detachment heat exchanger) using the 4 allen head screws in the panel (first remove the plastic plug).
2. Unlock the butterfly screws at the clamp of the heat exchanger ([2] pict. heat exchanger removal) with simultaneous careful removal of the reverse flow heat exchanger 2 ([5] pict. heat exchanger removal).
3. Unlock the angle bracket heat exchanger ([1] pict. heat exchanger removal) with simultaneous careful removal of the reverse flow exchanger 1 ([4] pict. heat exchanger removal), do the same with heat exchanger 3 ([6] pict. heat exchanger removal)

In order to ensure a safe assembly of the heat exchanger the above listed steps have to be executed in reverse order.

Maintenance	Every 3 months	If necessary	Hygiene Inspection
Check of the hygienic condition			X
Check the reverse flow heat exchanger for dirt	X		
Cleaning of the plate set with water (water or steam, the sheet of water should always follow the disc set from top to bottom) Clean the module chamber carefully Completely remove the dirty water		X	
Check the condensate and maintenance pan for dirt	X		
Cleaning of the condensate pan		X	
Check the function of the trap and water level, fill in water if necessary	X		
Check the bypass flap on free movement and repair it if necessary	X		

The water or the used cleaning agent should have a neutral ph-value (6 – 8).



► **Warning: The blades of the reverse flow heat exchanger are very sensitive to contact. Clean and remove with extreme caution!**


7.6 Panel filters

7.6.1 Startup



- Before installation of the filter all seals should be checked for correct fit. Clean the housing floor.
- Pay attention to the directional arrow for the air stream printed on the panel filters.
- The filter will be controlled by a differential pressure sensor. If the admissible differential pressure is exceeded, a signal will appear on the control panel to change the filter. In this case the filters must be changed immediately. More information can be found in the manual of the control system.


7.6.2 Operation



Pict. Panel filter overhead version

The panel filters will be fastened at the assembly frame with a tensioning angle rail. Draw the angle rail to the body in order to change the filter and remove it afterwards. Pay attention to the correct fit of the filter at the frame after the re-assembly. During the filter change check the seal and replace it if necessary.

7.6.3 Maintenance and Cleaning



The recommended final resistance for this filter version is 150 PA. Always replace panel filters completely. The filters can be fully incinerated and must be disposed of accordingly. Clean the housing bottom before installing the new filter.

Change the filter after 12 months of operation or down time at the latest. Note the filter change with name and date at the unit and in the maintenance book.

Maintenance	Every 3 months	If necessary	Hygiene Inspection
Check for dirt by differential pressure control	X	X	X
Check the filter element for damages	X		
Replacement of the filter insert		X	
Check the filter for impermeable fit	X	X	X
Check the measure control for the differential pressure.	X		X